



Scout DST 3-Wheel Travel Scooter









INSET A

INSET B

INSET C

INSET D





INSET E

INSET F

- Dynamic Suspension Technology (DST) features front and rear suspension coils for the most comfortable ride on all terrain (Figure D)
- Charge port located on the control panel and battery pack for easy charging
- Headlight
- Interchangeable color panels in red and blue
- Quick & easy disassembly
- Armrests are padded, contoured, width and angle adjustable (Figure F)
- Delta tiller with ergonomic throttle control (Figure E)
- Armrest covers with reflectors
- Large plastic basket with carry handle
- Height adjustable swivel seat with fold down backrest
- Anti-tip wheels
- Extended footboard provides ample space for taller users (Figure C)

PRODUCTS	Description	
SCOUTDST3	1/ea	
CDECIFICATIONIC	Description	
SPECIFICATIONS	Description	
Weight Capacity	325 lbs.	
Top Speed	4.25 mph	
Estimated Range	15 miles	
Max Climbing Angle	6°	
Turning Radius	45"	
Ground Clearance	2.5"	
Dimensions	42.5" (L) × 21.25" (W) × 36" (H)	
Seat Dimensions	17.5" (W) x 16" (D)	
Back Height	14"	
Controller	CURTIS 45A	
Motor	270W x 4700RPM	
Batteries	20AH	
Charger	2A	
Brakes	Electromagnetic	
Freewheel Mode	Yes	
Front Wheels	8" x 2"	
Rear Wheels	8" x 2"	
Anti-Tip Wheels	2" x ¾"	
Base Weight	60 lbs.	
Battery Weight (Pair)	30 lbs. (20 AH)	



SPECIFICATIONS	Description
Seat Weight	23 lbs
Heaviest Piece Weight	Front Section: 34 lbs.
Total Weight	113 lbs.
Warranty on Frame	Limited Lifetime
Warranty on Electronics, Controller, Drive-Trai	in Components 14 months
Warranty on Batteries	12 Months
PARTS	Description
LRM412103-11	SPEED DIAL KNOB, 1/ea
BC31001	SPEED DIAL, 1/ea
BC31009N	THROTTLE, 1/ea
<u>C11-076-00100</u>	BATTERY GAUGE, 1/ea
SC31034	HORN BUTTON, 1/ea
<u>c12-050-00501</u>	HORN, 1/ea
<u>c16-069-00400</u>	LIGHT SWITCH, 1/ea
<u>c18-069-00101</u>	KEY SWITCH, 1/ea
BCKEY	KEY, 1/ea
C18-071-00800	CHARGER PORT, 1/ea
c08-069-00101	UPPER TILLER COVER, 1/ea
c08-069-06600	LOWER TILLER COVER, 1/ea
c08-070-00100	FRONT SHROUD, 1/ea
SC31024	FOOT SHROUD, 1/ea
SC31027	BATTERY BOX HOLDER, 1/ea
c08-069-05500	REAR SHROUD, 1/ea
c01-070-00400	FRONT FRAME, 1/ea
c02-069-00100	TILLER, 1/ea
C08-069-06500	FRONT TILLER COVER, 1/ea
SC31054	HANDLE BAR COVER, 1/ea
BC35051	BASKET HOLDER, 1/ea
C02-069-00601	TILLER SWIVEL ASSEMBLY, 1/ea
12AH-SC31007	BATTERY BOX WITH BATTERIES, 1/ea
12AH-SC31006	BATTERY BOX ONLY, 1/ea
20AH-SC31050	BATTERY BOX WITH BATTERIES, 1/ea
20AH-SC31051	BATTERY BOX ONLY, 1/ea
BC20ACB	20 AMP CIRCUIT BREAKER, 1/ea
C01-069-01801	LATCHING FRAME, 1/ea
SC31031	BATTERY BOX CHARGER PORT, 1/ea
C12-060-00300	BATTERY FRAME CONTACT, 1/ea
LRM402109	12 AH BATTERY (TWO NEEDED), 1/ea
LRM412123	20 AH BATTERY (TWO NEEDED), 1/ea
9653060020002	WHEEL BEARING, 1/ea
C06-060-00200	REAR WHEEL ASSEMBLY, 1/ea
DST-005	AXLE BOLT ASSEMBLY, 1/ea
SC31025	HUB CAP, 1/ea
DST-013	SEAT W/SEAT PLATE W/O ARMRESTS, 1/ea
C07-069-00201	SEAT POST, 1/ea
C07-028-00404	LEFT ARMREST COMPLETE, 1/ea
C07-028-00504	RIGHT ARMREST COMPLETE, 1/ea
DST-016	SEAT PLATE, 1/ea
S31052	Accessory Knob, 1/ea
VENT-31	ARM PAD LEFT, 1/ea
VENT-32	ARM PAD RIGHT, 1/ea
SC31047	BATTERY BOX HOLD DOWN, 1/ea
SC31052	CONTROLLER, 1/ea